

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400435538

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: REBECCA HEIM

Name of Operator: KERR-MCGEE OIL &amp; GAS ONSHORE LP

Phone: (720) 929-6361

Address: P O BOX 173779

Fax: (720) 929-7361

City: DENVER State: CO Zip: 80217-

Email: REBECCA.HEIM@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: \_\_\_\_\_ Tel: \_\_\_\_\_

COGCC contact:

Email: \_\_\_\_\_

API Number 05-123-19096-00

Well Name: HSR-KNOX

Well Number: 16-3

Location: QtrQtr: SESE Section: 3 Township: 5N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 64369

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.422750

Longitude: -104.872970

GPS Data:

Date of Measurement: 06/28/2006

PDOP Reading: 6.0

GPS Instrument Operator's Name: HORSESHOE

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☐ Other \_\_\_\_\_Casing to be pulled: ☐ Yes ☐ No Estimated Depth: \_\_\_\_\_Fish in Hole: ☐ Yes ☐ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
CODELL	CODL	7120	7127		B PLUG CEMENT TOP	6750
NIOBRARA	NBRR	6803	6937		B PLUG CEMENT TOP	6750

Total: 2 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	23	642	550	642	0	VISU
1ST	7+7/8	4+1/2	11.6	7,261	150	7,261	6,506	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6740 with 2 sacks cmt on top. CIPB #2: Depth 95 with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 350 sks cmt from 1510 ft. to 100 ft. Plug Type: CASING Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 6480 ft. with 100 sacks. Leave at least 100 ft. in casing 6284 CICR Depth

Perforate and squeeze at 3780 ft. with 500 sacks. Leave at least 100 ft. in casing 3811 CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 22 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 06/07/2013

\*Wireline Contractor: J-W WIRELINE \*Cementing Contractor: SANJEL

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: REBECCA HEIM

Title: REGULATORY ANALYST II Date: \_\_\_\_\_ Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

### CONDITIONS OF APPROVAL, IF ANY:

### Attachment Check List

Att Doc Num	Name
400435551	OPERATIONS SUMMARY
400435552	CEMENT JOB SUMMARY
400435554	CEMENT JOB SUMMARY
400435555	CEMENT JOB SUMMARY
400435556	WELLBORE DIAGRAM
400435557	WIRELINE JOB SUMMARY
400435559	WIRELINE JOB SUMMARY
400435560	WIRELINE JOB SUMMARY

Total Attach: 8 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)