

Document Number:  
400765798

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: REBECCA HEIM  
 Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6361  
 Address: P O BOX 173779 Fax: (720) 929-7361  
 City: DENVER State: CO Zip: 80217- Email: REBECCA.HEIM@ANADARKO.COM

**For "Intent" 24 hour notice required,** Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 Email: \_\_\_\_\_

API Number 05-123-14843-00 Well Number: L 16-16  
 Well Name: STATE  
 Location: QtrQtr: SESE Section: 16 Township: 3N Range: 66W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: 72-3021-S  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.219070 Longitude: -104.774700  
 GPS Data:  
 Date of Measurement: 06/20/2006 PDOP Reading: 2.9 GPS Instrument Operator's Name: Paul Tappy  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7349	7359	04/16/2014	B PLUG CEMENT TOP	7280

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	540	500	540	0	CALC
1ST	7+7/8	2+7/8	6.5	7,501	350	7,501	6,500	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7280 with 20 sacks cmt on top. CIBP #2: Depth 80 with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>20</u> sks cmt from <u>5600</u> ft. to <u>4900</u> ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input type="checkbox"/>
Set <u>320</u> sks cmt from <u>4535</u> ft. to <u>4120</u> ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>640</u> sks cmt from <u>1260</u> ft. to <u>120</u> ft.	Plug Type: <u>STUB PLUG</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>50</u> sks cmt from <u>80</u> ft. to <u>0</u> ft.	Plug Type: <u>STUB PLUG</u>	Plug Tagged: <input type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set 0 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: 1260 ft. of 2+7/8 inch casing Plugging Date: 01/05/2015  
 \*Wireline Contractor: WARRIOR \*Cementing Contractor: SANJEL  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: REBECCA HEIM  
 Title: SR. REGULATORY ANALYST Date: \_\_\_\_\_ Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

\_\_\_\_\_

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400765799	OPERATIONS SUMMARY
400765800	WELLBORE DIAGRAM
400765801	CEMENT JOB SUMMARY
400765802	WIRELINER JOB SUMMARY
400765803	CEMENT BOND LOG
400765804	CEMENT JOB SUMMARY
400765806	WIRELINER JOB SUMMARY

Total Attach: 7 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)