

Well Name : Mount Hope Green 31  
API # : 075-06347



Photo 1: Rigging up on well.



Photo 2: Tripping out tubing.

Well Name : Mount Hope Green 31  
API # : 075-06347



Photo 3: Wireline setting CIBP and running CBL on casing.



Photo 4: Completed pressure test.

Well Name : Mount Hope Green 31  
API # : 075-06347



Photo 5: Cement crew on location to pump cement plugs.



Photo 6: Equipment rigged into well to complete cement plug.



Well Name : Mount Hope Green 31  
API # : 075-06347



Photo 7: Returns to tank.



Photo 8: Rigging down for move.

Well Name : Mount Hope Green 31

API # : 075-06347



Photo 9: Cement topped off in surface casing.



Photo 10: Marker plate welded onto surface casing.



Well Name : Mount Hope Green 31

API # : 075-06347



Photo 11: View of location.



Photo 12: Marked surface casing.  
Cement pump jack base and power poles  
that need to be removed.

Well Name : Mount Hope Green 31  
API # : 075-06347



Photo 13: View of location.



Photo 14: Power pole and electrical equipment to be removed.