

Proposed work WRIGHT 31- 1.

1. Excavate a 200 bbl emergency workover pit and line it.
2. Move in, rig up Yetter Well Service
3. TOH with rods and tubing.
4. TIH with tubing and circulate to 4700 feet.
5. TOH tubing, TIH Tubing with cast Iron bridge plug. Set plug. At 4600 or deeper.
6. TOH tubing.
7. TIH liner casing to setting depth. Which is at least 4590.
8. Cement liner casing with 168 sacks of Cement, and additives.
9. Circulate cement to surface. Allow cement to set.
10. TIH tubing and drill out wiper plug and cast Iron bridge plug.
11. Circulate to 4809. TOH with tubing.
12. TIH To swab and clean up formation.
13. POP.