

Document Number:  
402631800

Date Received:  
03/22/2021

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 76840 Contact Name: Jeff Schneider  
 Name of Operator: SCHNEIDER ENERGY SERVICES INC Phone: (970) 867-9437  
 Address: P O BOX 889 Fax: (970) 867-9137  
 City: FORT MORGAN State: CO Zip: 80701 Email: jeff@schneiderenergy.com

**For "Intent" 24 hour notice required,** Name: Petrie, Erica Tel: (303) 726-3822  
**COGCC contact:** Email: erica.petrie@state.co.us

Type of Well Abandonment Report:  Notice of Intent to Abandon  Subsequent Report of Abandonment

API Number 05-123-05372-00  
 Well Name: APRIL Well Number: 12-14  
 Location: QtrQtr: SWNW Section: 14 Township: 7N Range: 60W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: 56600  
 Field Name: LADY K Field Number: 47680

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.576928 Longitude: -104.067168  
 GPS Data: GPS Quality Value: 2.5 Type of GPS Quality Value: PDOP Date of Measurement: 10/06/2010

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	6796	6804			
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	10+3/4	J-55	32.75	0	97	75	97	0	VISU
1ST	7+7/8	4+1/2	J-55	10.5&1.6	0	6948	200	6948	5940	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6750 with 2 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>50</u>	sks cmt from <u>150</u>	ft. to <u>0</u>	ft.	Plug Type: <u>ANNULUS</u>	Plug Tagged: <input type="checkbox"/>
Set <u>10</u>	sks cmt from <u>150</u>	ft. to <u>0</u>	ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>2</u>	sks cmt from <u>500</u>	ft. to <u>475</u>	ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at 6000 ft. with 50 sacks. Leave at least 100 ft. in casing 5950 CICR Depth  
 Perforate and squeeze at 1630 ft. with 40 sacks. Leave at least 100 ft. in casing 1580 CICR Depth  
 Perforate and squeeze at 550 ft. with 40 sacks. Leave at least 100 ft. in casing 500 CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_  
 Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105  Yes  No

Technical Detail/Comments:

There is no CBL for this well. Our plan is to set the CIBP @ 6760' and spot 2 sacks of cement on top of CIBP, then run a CBL to determine the top of the cement. The CBL will be emailed to the area engineer for approval or changes in the plugging orders before we procede with the plugging operations.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jeff Schneider  
 Title: President Date: 3/22/2021 Email: jeff@schneiderenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 4/19/2021

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 10/18/2021

## Condition of Approval

### COA Type

### Description

	<p>Venting Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Venting Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Plugging 1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) Contact COGCC Area Inspector prior to commencing plugging operations. 3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained. 4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Tag at tops specified or shallower. Notify COGCC Area Engineer before adding cement to previous plug. 5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap. 6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 7) Properly abandon flowlines as per Rule 1105. Pursuant to Rule 911.a. Closure of Oil and Gas Facilities, Operator will submit Site Investigation and Remediation Workplans via Form 27 for COGCC prior approval before cutting and capping the plugged well, conducting flowline abandonment, and removing production equipment. Pursuant to Rule 1105.f. Abandonment Verification, within 90 days of an operator completing abandonment requirements for a flowline or crude oil transfer line, an operator must submit a Field Operations Notice, Form 42-Abandonment of Flowlines for on-location flowlines, and a Flowline Report, Form 44, for off-location flowlines or crude oil transfer lines. 8) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations. 9) After placing the shallowest hydrocarbon isolating plug (6750'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC Area Engineer before continuing operations. 10) Add 40 sx squeeze at 6000'(depending on CBL results) for Niobrara isolation. If CICR is not used, leave 100' of cement in the casing and tag if circulation is not maintained while pumping and displacing the plug to depth. 11) Move 40 sx squeeze from 1500' to 1630' for Upper Pierre isolation. If CICR is not used, leave 100' of cement in the casing and tag if circulation is not maintained while pumping and displacing the plug to depth. 12) Add 40 sx squeeze at 550' for Niobrara isolation. If CICR is not used, leave 100' of cement in the casing and tag if circulation is not maintained while pumping and displacing the plug to depth.</p>

3 COAs

## Attachment List

### Att Doc Num

### Name

402631800	FORM 6 INTENT SUBMITTED
402636136	WELLBORE DIAGRAM
402636138	WELLBORE DIAGRAM

Total Attach: 3 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Groundwater: L-FH, Upper Pierre Deepest Water Well: 100'(2 wells-1 MI), 420'(11 wells-2 mi) Log: 8/9/89 Keota 1 123-14360, L-FH base 500', Upper Pierre base 1520'	04/19/2021
Engineer	•Dryer 1 123-24938 NWNW 14 7N60W Niobrara Top 6090'	04/19/2021
OGLA	COGCC OGLA Staff conducted its review of this Form 6 Notice of Intent (NOI) Well Abandonment Report in the context of SB 19-181 and the current rules. This Form 6 complies with applicable COGCC Rules and is adequately protective of public health, safety, welfare, the environment, and wildlife resources.	04/01/2021
Permit	-Confirmed as-drilled well location. -Production reporting up-to-date. -Confirmed productive interval docnum: 215616. -Reviewed WBDs. -Pass.	03/23/2021

Total: 4 comment(s)