

FORM

6

Rev  
11/20

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

403377967

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1099 18TH STREET SUITE 1500

Fax:

City: DENVER

State: CO

Zip: 80202

Email: valerie.danson@pdce.com

For "Intent" 24 hour notice required,

Name: Medina, Justin

Tel: (720) 471-0006

COGCC contact:

Email: justin.medina@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-001-07238-00

Well Name: STATE-FERGUSON

Well Number: 1

Location: QtrQtr: SWSW

Section: 36

Township: 1S

Range: 67W

Meridian: 6

County: ADAMS

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.917050

Longitude: -104.843120

GPS Data: GPS Quality Value: 1.5 Type of GPS Quality Value: PDOP Date of Measurement: 02/21/2023

Reason for Abandonment: ☐ Dry ☐ Production Sub-economic ☐ Mechanical Problems☒ Other Re-enter to Re-plug for PDC's Adams Crossing developmentCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J55	23	0	128	150	128	0	VISU

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 237 sks cmt from 7379 ft. to 6879 ft. Plug Type: OPEN HOLE Plug Tagged: ☒

Set 100 sks cmt from 2470 ft. to 2270 ft. Plug Type: OPEN HOLE Plug Tagged: ☒

Set 237 sks cmt from 1311 ft. to 884 ft. Plug Type: OPEN HOLE Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 318 sacks half in. half out surface casing from 670 ft. to 0 ft. Plug Tagged: ☒

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing

Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_ Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_

\*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

State-Ferguson 1 (05-001-07238)/Re-Enter to Re-Plug Procedure (Intent)

Original Abandon Date: 5/19/1977

Abandoned Formation: N/A (DA well)

Upper Pierre Aquifer: 1780'-2370'

Fox Hills: 984' – 1211'

Depest Water Well: 1140'

TD: 8330'

Surface Casing: 8 5/8" 23# @ 128' w/ 150 sxs cmt

Open Hole: 7 7/8" @ 128'-8330' (Open Hole OD is assumed)

Existing Plugs: 1230' – 950' (110 sxs cmt), 125' – 75' (25 sxs cmt), 25' to surface (10 sxs cmt)

Proposed Procedure:

1. Dig out to find wellhead and check pressure.

2. Cut cap off, extend surface pipe to achieve ground level.

3. MIRU WO unit, ND wellhead, NU BOP, tally all pipe to be ran in well.

4. Mill cement, cement btm is approximately 1230' according to well history data.

5. Wash run down to 7429' or depth that well allows.

6. PU tubing to 7379'. RU cementing company. Mix and pump 237 sxs 15.8#/gal CI G cement down tubing. (Top of Niobrara @ 7429', coverage from 7379'-6879') PU tubing above plug and SI well.

a. Wait 4 hours and tag plug

7. PU tubing to 2470'. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing (Pierre Aquifer coverage from 2470'-2270'). PU tubing above plug and SI well.

a. Wait 4 hours and tag plug

8. PU tubing to 1311'. Mix and pump 237 sxs 15.8#/gal CI G cement down tubing (Fox Hills coverage from 1311'-884'). PU tubing above plug and SI well.

a. Wait 4 hours and tag plug

9. PU tubing to 670'. Mix and pump 318 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. Top off if necessary.

10. RDMO WO unit. Remove extension of surface pipe.

11. Weld on cap with ID plate, inscribed with well location, and identity. Backfill, clean location. Re-Entry complete.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Valerie Danson

Title: Reg Analyst

Date: \_\_\_\_\_

Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_

Expiration Date: \_\_\_\_\_

**COA Type**

**Description**

0 COA	

**Attachment List**

**Att Doc Num**

**Name**

403378006	LOCATION PHOTO
403378007	WELLBORE DIAGRAM
403378008	WELLBORE DIAGRAM
403406535	SURFACE OWNER CONSENT

Total Attach: 4 Files

**General Comments**

**User Group**

**Comment**

**Comment Date**

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)