

FORM  
6Rev  
12/05State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400402197

Date Received:

04/12/2013

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 55575

Contact Name: Jeff Reindl

Name of Operator: MCELVAIN ENERGY INC

Phone: (303) 893-0933 x375

Address: 1050 17TH ST STE 2500

Fax: (303) 893-0914

City: DENVER State: CO Zip: 80265-

Email: jeff.reindl@mcelvain.com

For "Intent" 24 hour notice required, Name: QUINT, CRAIG Tel: (719) 767-8939

COGCC contact: Email: craig.quint@state.co.us

API Number 05-125-10890-00

Well Name: WINGFIELD

Well Number: 9-12

Location: QtrQtr: SWNW Section: 9 Township: 2S Range: 45W Meridian: 6

County: YUMA

Federal, Indian or State Lease Number:

Field Name: TIERRA PLANO

Field Number: 80980

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.899660

Longitude: -102.428550

GPS Data:

Date of Measurement: 08/05/2008

PDOP Reading: 3.0

GPS Instrument Operator's Name: DUANE RUSSELL

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2262	2282			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	10	7	17	322	80	322	0	VISU
1ST	6+1/8	4+1/2	10.5	2,457	75	2,457	1,480	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2210 with 25 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 1650 ft. to 1311 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 65 sacks half in. half out surface casing from 332 ft. to 0 ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Please find the attached P&A program. Please do not hesitate to contact me with any questions. Thanks!

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jeff Reindl

Title: Operations Engineer Date: 4/12/2013 Email: jeff.reindl@mcelvain.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 5/14/2013

### CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 11/13/2013

- 1) Provide 24 hour notice of MIRU to Craig Quint at 719-767-8939 or e-mail at craig.quint@state.co.us.
- 2) Tag shoe plug if cement not circulated to surface on shoe plug. Top up casing and annulus from 50' to surface as needed.
- 3) Form 15 required for plugging pit per 100 series definitions and 900 series rules.

### **Attachment Check List**

Att Doc Num	Name
400402197	FORM 6 INTENT SUBMITTED
400402671	WELLBORE DIAGRAM

Total Attach: 2 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
Engineer	Jeff is listed as an agent. Emailed him regarding Form 15 required for plugging pit mentioned in attached procedure.	5/14/2013 4:04:28 PM
Permit	Requested that Jeff Reindl submit a form 1A. Drilling completion report # 2036385 dated 8/14/2008	4/15/2013 5:12:07 AM

Total: 2 comment(s)