

Byron Oil Industries Inc
Price-Degenhart #1 P&A
SESE Sec 34 T2S R58W
Lat: 39.828953 Long: -103.855159

Procedure:

1. Provide notice of MIRU to COGCC prior to MIRU per Form 6 COA or BLM Sundry.
2. Call foreman or Lead Operator before rig up to isolate and remove automation and production equipment. Install fence if needed.
3. Prepare location for base beam rig.
4. MIRU workover rig. NU wellhead and 5k BOP. Test BOP.
5. Kill well, as necessary, with water containing biocide. ND wellhead. NU BOP's. Unseat landing joint and lay down.
6. TOOH and stand back 2-3/8" tbg.
7. MIRU wireline services. PU CIBP for 4-1/2" 10.5# J-55 csg and RIH to 5575', set CIBP. POOH.
8. Load hole with water. Pressure test plug to 1500 psi for 15 min. Run CBL from 5575' to 4500' to verify estimated top of cement @ 4690'.
9. RDMO wireline services.
10. TIH w/ 2-3/8" tubing (hydrotesting to 3000 psi) to CIBP @ 5575'.
11. MIRU cementing services. Pressure test lines to 4500 psi, then mix and pump 20 sx of Class G neat at 1.15 ft3/sx, 15.8 ppg on top of CIBP. RDMO cementing services.
12. POOH to surface casing and wait four hours. RIH and tag top of cement. Record tag depth. If tag is deeper than 5,475', contact engineer.
13. POOH & stand back tubing for next depth (280'), LD remainder.
14. MIRU WL. TIH with jet cutter and cut casing at the "closest joint" to 180' (50' below Surface CSG). RDMO WL.
15. TIH with 2-3/8" to 280'. RU cement crew and pump 77 sks of 15.8 ppg Class G neat cement and bring cement to surface. POOH with 2-3/8" tubing. Wait four hours and tag top of cement. If cement has fallen, top off to surface.
16. RDMO WO rig.
17. Once surface plug has set, cut casing to 5' below ground level and weld on plate to seal the wellbore. Inscribe the well's legal location, well name and number, and API number on the plate as shown below:

Price-Degenhart #1
05-001-07346
660' FSL 600' FEL SESE Sec 34 2S58W
18. Backfill hole and reclaim surface to original conditions.
19. Submit Form 6 to COGCC. Provide "As Plugged" wellbore diagram identifying the specific plugging completed.

See Proposed WBD & Form 6 Attachments